



## Arctic 3G Gateway User Manual



Document version 1.1  
Firmware version 1.2.5  
Modified January 27, 2009  
©Viola Systems Ltd

# Contents

<b>1</b>	<b>Introduction</b>	<b>6</b>
1.1	About the Arctic 3G Gateway . . . . .	6
1.2	Arctic 3G features . . . . .	6
1.3	Packaging information . . . . .	6
<b>2</b>	<b>Hardware description</b>	<b>7</b>
2.1	Front panel . . . . .	7
2.2	Back panel . . . . .	7
2.3	Side panel . . . . .	8
2.4	LEDs . . . . .	8
2.4.1	Status LEDs . . . . .	8
2.4.2	Ethernet LEDs . . . . .	9
2.4.3	3G module status LED . . . . .	9
2.5	Networking . . . . .	9
2.5.1	Mobile WAN (3G) . . . . .	9
2.5.2	Ethernet WAN . . . . .	10
2.5.3	Ethernet LAN . . . . .	10
2.6	Serial ports . . . . .	10
2.6.1	Serial console port . . . . .	10
2.6.2	Serial port 1 . . . . .	11
2.6.3	Serial port 2 . . . . .	12
2.7	Power switch and reset button . . . . .	12
2.8	Power connector . . . . .	12
2.9	DIN rail mounting . . . . .	12
2.10	Product Label . . . . .	13
2.11	Accessories . . . . .	13
<b>3</b>	<b>Quick Installation</b>	<b>14</b>
3.1	Connection principle . . . . .	14
3.2	Connecting cables . . . . .	14
3.3	Logging in to Arctic 3G . . . . .	14
3.4	Configuring Ethernet LAN . . . . .	15
3.5	Configuring Mobile WAN (3G) . . . . .	15
3.6	Configuring default gateway . . . . .	16
<b>4</b>	<b>Network Configuration</b>	<b>17</b>
4.1	Configuration screens . . . . .	17
4.1.1	Host and domain names . . . . .	17
4.1.2	Ethernet WAN . . . . .	17
4.1.3	Mobile WAN (3G) . . . . .	18
4.1.4	WAN Failover . . . . .	18
4.1.5	Ethernet LAN . . . . .	19
4.1.6	Network monitor . . . . .	19
4.2	Routing . . . . .	20
4.2.1	Routing parameters . . . . .	20
4.2.2	Default route . . . . .	20
4.2.3	WAN redundancy/failover . . . . .	20
4.2.4	Routing serial <-> Ethernet . . . . .	20
4.3	Network services . . . . .	20

4.3.1	DNS proxy . . . . .	20
4.4	Network status information . . . . .	21
4.4.1	System status screen . . . . .	21
4.4.2	Mobile WAN (3G) status LEDs . . . . .	21
4.4.3	Modem info screen . . . . .	21
<b>5</b>	<b>Serial Port Configuration</b>	<b>22</b>
5.1	Configuring serial gateway . . . . .	22
<b>6</b>	<b>Additional System Configuration</b>	<b>23</b>
6.1	Changing system password . . . . .	23
6.2	Date and time . . . . .	23
6.3	System log . . . . .	23
6.4	Factory default settings . . . . .	23
6.5	Firmware update . . . . .	24
<b>7</b>	<b>Troubleshooting</b>	<b>25</b>
<b>8</b>	<b>Technical Specifications</b>	<b>26</b>
<b>9</b>	<b>Limited Warranty</b>	<b>27</b>
<b>10</b>	<b>Technical Support</b>	<b>28</b>

# Copyright and Trademark

Copyright © 2008, Viola Systems Ltd. All rights to this manual are owned solely by Viola Systems Ltd. (referred in this manual as Viola Systems). All rights reserved. No part of the contents of this manual may be transmitted or reproduced in any form or by any means without the written permission of Viola Systems.

Ethernet is a trademark of XEROX Corporation. Windows and Internet Explorer are trademarks of Microsoft Corporation. Netscape is a trademark of Netscape Communications Corporation. Linux is a Registered Trademark of Linus Torvalds. All other product names used in this manual are the properties of their respective owners and are acknowledged.

## Contact Information

Viola Systems Ltd.  
Lemminkäisenkatu 14 - 18 B  
FIN-20520  
Turku  
Finland

Technical Support  
Phone: +358 (0)20 1226 226  
Fax: +358 (0)20 1226 220  
E-mail: [support@violasystems.com](mailto:support@violasystems.com)  
On-line: <http://www.violasystems.com/>

# Disclaimer and Revisions

Viola Systems reserves the right to change the technical specifications or functions of its products, or to discontinue the manufacture of any of its products or to discontinue the support of any of its products, without any written announcement and urges its customers to ensure, that the information at their disposal is valid.

Viola software and programs are delivered “as is”. The manufacturer does not grant any kind of warranty including guarantees on suitability and applicability to a certain application. Under no circumstances is the manufacturer or the developer of a program responsible for any possible damages caused by the use of a program. The names of the programs as well as all copyrights relating to the programs are sole property of Viola Systems. Any transfer, licensing to a third party, leasing, renting, transportation, copying, editing, translating, modifying into another programming language or reverse engineering for any intent is forbidden without the written consent of Viola Systems.

Viola Systems has attempted to verify all information in this manual as of the publication date. We assume no responsibility for any errors that may appear in this guide. Information in this manual may change without prior notice from Viola Systems.

## Revision History

09/2008	Version 0.1 First draft
12/2008	Version 1.0 First release version
01/2009	Version 1.1 Fixed operating voltage specifications

# Warranty and Safety Instructions

Read these safety instructions carefully before using the product:

Warranty will be void, if the product is used in any way, which is in contradiction with the instructions given in this manual, or if the product has been tampered with.

The devices mentioned in this manual are to be used only according to the instructions described in this manual. Faultless and safe operation of the devices can be guaranteed only if the transport, storage, operation and handling of the devices is appropriate. This also applies to the maintenance of the products.

To prevent damage both the product and any terminal devices must always be switched OFF before connecting or disconnecting any cables. It should be ascertained that different devices used have the same ground potential. Before connecting any power cables the output voltage of the power supply should be checked.

This product is not fault-tolerant and is not designed, manufactured or intended for use or resale as on-line control equipment in hazardous environments requiring fail-safe performance, such as in the operation of nuclear facilities, aircraft navigation or communication systems, air traffic control, direct life support machines, or weapons systems, in which the failure of our hardware or software could lead directly to death, personal injury, or severe physical or environmental damage.

# Chapter 1

## Introduction

### 1.1 About the Arctic 3G Gateway

The Arctic 3G Gateway product is an industrial grade wireless router for demanding IP connectivity applications.

For the rest of this documentation, the Arctic 3G Gateway is referred to as Arctic 3G.

For the rest of this documentation, the Viola M2M Gateway is referred to as M2M Gateway.

### 1.2 Arctic 3G features

Arctic 3G offers different advanced features. Flexible design allows the system to gain extra features if required.

#### High speed wireless connectivity

Arctic 3G has support for the latest mobile technologies, such as 3G and HSDPA. This allows the remote control of wide bandwidth services such as video surveillance or high amount of measurement and control channels.

#### Flexible routing

Arctic 3G can be configured to fit in all kinds of networks. It also has full support for Serial – Ethernet routing of industrial network protocols.

#### High security

Arctic 3G has highly configurable firewall and secure VPN support for secure connectivity.

#### Redundancy and reliability

Arctic 3G offers redundancy against network breakdowns and remote VPN endpoint breakdowns. This allows the overall system to achieve high availability numbers. These functionalities added to high reliability of both the hardware and software make very robust system suitable in harsh and demanding industrial environments.

#### Remote management

Arctic 3G can be managed remotely and it is easy to move configurations between units.

### 1.3 Packaging information

The product package contains the following items:

- Arctic 3G device
- 3-pin power connector
- Antenna
- Arctic 3G Quick Start Guide

Additional accessories are available, see section 2.11.

## Chapter 2

# Hardware description

This section describes the physical interfaces on Arctic 3G.

### 2.1 Front panel

Arctic 3G front panel is shown in figure 2.1.




Figure 2.1: Front panel

LEDs and switches (from left to right) with section reference to more detailed information:

- |                                      |  |
|--------------------------------------|--|
| 1. Error LED (section 2.4)           | 4. Ethernet LAN ports (section 2.5.3)  |
| 2. Reset button (section 2.7)        | 5. LEDs (section 2.4)                  |
| 3. Ethernet WAN port (section 2.5.2) | 6. Serial console port (section 2.6.1) |

### 2.2 Back panel

Arctic 3G back panel is shown in figure 2.2.




Figure 2.2: Back panel

Connectors (from left to right):

- |   |                                  |
|---|----------------------------------|
| 1. Serial port 1 (section 2.6.2)                          | 4. Power switch                  |
| 2. Serial port 1 configuration DIP switches (section 2.7) | 5. Power connector (section 2.8) |
| 3. Serial port 2 (section 2.6.3)                          |                                  |



## 2.3 Side panel

Arctic 3G side panel has the SIM card slot and an antenna connector. See section 2.5.1 for more information about wireless functionality.




Figure 2.3: Side panel

Items (from left to right):

- |                         |                            |
|-------------------------|----------------------------|
| 1. SIM card slot        | 3. SIM card release button |
| 2. 3G module status LED | 4. Antenna connector       |

## 2.4 LEDs

### 2.4.1 Status LEDs

Arctic 3G has 11 status LEDs. They are located on the front panel (see section 2.1).

LED	State	Meaning
Error	On	Unit is restarting. LED should turn off after restart (usually about 30 seconds).
	Blinking	If the LED is constantly turned on for a long time you should contact technical support. There is something wrong with the unit or the power supply causes the unit to restart constantly. You should try with another power supply and if that does not help, contact technical support.
	Off	Unit is operating normally
RUN	Blinking	Unit is operating normally
	Off	If the unit is turned on and RUN led is not blinking, the system has caught an error and is waiting for restart. The unit should restart soon.
VPN	On	VPN connection is up
	Blinking	VPN connection is starting
	Off	VPN connection is disabled
FW	-	Reserved for future use
SIM	On	SIM card has been found and it is ready for use.
	Blinking	SIM card initialization is in progress.
	Off	SIM card is not in use
SIG	On	Signal level is normal or good (better than -95 dBm)
	Blinking	Signal level is weak (between -110 dBm and -95 dBm)
	Off	There is no signal (below -110 dBm)
COM	On	3G connection is up
	Blinking	3G connection is starting. If the connection is not coming up, check the SIM and SIG LEDs
	Off	3G connection is stopped
GPS	-	Reserved for future use
USR	-	Reserved for future use
RS1	-	Reserved for future use
RS2	-	Reserved for future use

Table 2.1: LED description

## 2.4.2 Ethernet LEDs

All Ethernet ports have two LEDs to indicate the ports link and activity status.

LED	State	Meaning
Green	On	Link on
	Blink	Data received
	Off	Link off
Yellow	On	Full duplex
	Off	Half duplex

Table 2.2: Ethernet LED description

## 2.4.3 3G module status LED

3G module has its own status LED to indicate the link status. LED is located on side panel in the SIM card slot (see section 2.3) Red blink means there is no SIM card, green blink means the 3G connection is up.

## 2.5 Networking

### 2.5.1 Mobile WAN (3G)

Arctic 3G has a high speed wireless functionality which allows the use of bandwidth demanding wireless applications. Arctic 3G supports wireless data speeds up to 1.8Mbit/s, however the practical data transfer rates depend on SIM card speed and wireless network capacity.

Networks	Frequencies	Maximum data rates
UMTS with HSDPA (cat 11/12)	2100 MHz	1.8Mbps downlink / 384kbps uplink
EDGE / GPRS class 10	850/900/1800/1900 MHz	216 kbps downlink/ 108 kbps uplink

Table 2.3: Mobile WAN (3G) specifications

Antenna connector type is SSMB-nano. Adapters for FME antennas are available, Viola Systems order code is 3450.

To use wireless connection, SIM card with data transfer enabled is needed. To install SIM card:

1. Turn off the unit
2. Insert the SIM card into slot so the the contacts are facing down and the notch on the corner is facing out
3. Gently push the card in the slot with pointy object, i.e. pen or unfolded paper clip
4. The card should be in place when the notch on the card is inside the slot and behind the spring

To eject the SIM card from the slot, press the small button below the SIM cards notched corner. Use pointy object like unfolded paper clip or screw driver to do this. When the button is pressed, the card will pop outwards and can be removed.

Note: It is not recommended to insert or remove the SIM card while the Arctic 3G is turned on



Figure 2.4: SIM card installation

### 2.5.2 Ethernet WAN

Arctic 3G has one physical port for Ethernet WAN. Specifications are shown in table 2.4.


 Connector	Number of ports	1
	Speed	10Base-T, 100Base-TX
	Duplex	Half and Full
	Auto-negotiation	Yes
	Recommended cabling	Cat5 or better

Table 2.4: Ethernet WAN specifications

If Ethernet WAN interface is directly connected to computer, crossover cable must be used. Ethernet WAN interface does not support automatic MDI/MDIX detection.

### 2.5.3 Ethernet LAN

Arctic 3G has three physical ports for Ethernet LAN. These ports are connected to a common switch. Specifications are shown in table 2.5.


 Connector	Number of ports	3
	Speed	10Base-T, 100Base-TX
	Duplex	Half and Full
	Auto-negotiation	Yes
	Recommended cabling	Cat5 or better

Table 2.5: Ethernet LAN specifications

If Ethernet LAN interface is directly connected to computer, both crossover and straight cables can be used. Ethernet LAN interface supports automatic MDI/MDIX detection.

## 2.6 Serial ports


Arctic 3G has two application serial ports and one serial console port.

Serial port 1 is configurable to multiple serial formats (RS-232/422/485), while serial port 2 supports only RS-232 data mode.

Serial port connectors are 9-pin D-sub (male) connectors. Serial ports enact as DTE devices.

#### 2.6.1 Serial console port

Serial console connector is located in Arctic 3G front panel (see figure 2.1). Connector type is RJ45. Connector is described in table 2.6.



CONSOLE

Connector diagram

Pin	Function
1	CTS
2	DSR
3	RXD
4	GND
5	GND
6	TXD
7	DTR
8	RTS

Connector pinout

Baud rate	115200
Data bits	8
Parity	No parity
Stop bits	1
Flow control	No flow control

Serial port configuration

Table 2.6: Serial console



### 2.6.3 Serial port 2

Connector diagram

Pin	Function
1	DCD
2	RXD
3	TXD
4	DTR
5	GND
6	DSR
7	RTS
8	CTS
9	RI

Connector pinout

Baud rate	115 - 230400
Data bits	8
Parity	No parity
Stop bits	1
Flow control	No flow control

Serial port configuration

Table 2.10: Serial port 2

Serial port 2 supports only RS-232 data mode.

## 2.7 Power switch and reset button

**Power switch** is located on back panel. It turns the unit on and off.

**Reset button** is located on front panel. Press shortly to reset the unit. Reset button can be used to restore factory default settings. To restore factory default settings, reset the unit by keeping the reset button pressed down until all the status LEDs blink. This indicates the factory presets have been applied.

## 2.8 Power connector

Arctic 3G has a 3-pin power connector. Pinout and voltage limits are described in table 2.11. Supplied plug type is *Phoenix Contact MC 1,5 / 3-STF-3,5* with screw fastening.


 <p>Connector</p>	Pin	Symbol	Function
	1	+	Voltage in, positive / 11 ... 18 VDC, 400 mA
	2	-	Voltage in, negative
	3	GND	Extra ground connection

Table 2.11: Power supply connector

Arctic 3G can be also used with 2-pin power connector, pin 3 left unconnected. The unit is protected against reversed polarity within the limits of the specified voltages.

Viola Systems default power supply for Arctic 3G can be ordered with order code 3020. Note that the power supply is not included in standard Arctic 3G package.

## 2.9 DIN rail mounting

Arctic 3G has mounting holes for optional DIN rail mounting brackets. Viola Systems order code for DIN rail mounting kit is 3003. Contact your local Viola Systems distributor for more details.

Mounting instructions:

1. Required tools and accessories are: DIN rail mounting kit (2 mounting brackets and 4 screws), screw driver
2. Use the screw driver to attach the screws to bottom panel of the Arctic 3G. DIN rail brackets can be installed to either diagonally or horizontally depending on the wanted DIN rail installation angle.
3. Figure 2.5 shows example installation.




Figure 2.5: DIN rail example installation

## 2.10 Product Label

Product label is found on the bottom of the device and it contains the basic information about the unit such as product name, serial number and MAC addresses of Ethernet ports.



Figure 2.6: Product label

## 2.11 Accessories

Viola Systems supplies certain accessories for Arctic 3G. Possible accessories are listed in table 2.12.

Accessory	Order code
Serial console adapter: RS232 to RJ45	3170
Antenna adapter: SSMB-nano to FME	3450
DIN rail mounting kit: 2 DIN rail clips with screws	3003
Optional power supply: 12V/1.5A with universal 100-240VAC IEC input	3020
Accessory kit: Serial console adapter, Ethernet cables, power supply	3221

Table 2.12: Arctic 3G accessories

## Chapter 3

# Quick Installation

This chapter describes how to configure the WAN network interfaces on Arctic 3G.

### 3.1 Connection principle

Arctic 3G has three network interfaces, Ethernet WAN, Mobile WAN (3G) and Ethernet LAN. WAN interfaces are used for connecting Arctic 3G to public Internet or private APN. Ethernet LAN is used for connecting other Ethernet devices to Arctic 3G's local network.

WAN interfaces can be configured to get redundant system where one WAN automatically gets traffic if the other one goes down. For example, if the Ethernet LAN goes down, the traffic will be automatically switched to mobile 3G and back when the Ethernet interface comes up again. This way the availability of the remote system will be better than with just one interface.

### 3.2 Connecting cables

1. Verify that the power switch is in the OFF position
2. Connect the Ethernet cable between Arctic 3G (Ethernet LAN connector) and your configuration computer
3. Connect power supply to Arctic 3G and toggle power the switch to ON position
4. The error LED should turn on immediately after the power switch turned on
5. After the system has initialized, the Error LED turns off and the RUN LED starts to blink

### 3.3 Logging in to Arctic 3G

This section describes how to log in to Arctic 3G using web configuration menu.

1. Configure your computer to use the same IP address space than Arctic 3G (laptop IP for example 10.10.10.11 with netmask 255.0.0.0). Check with ping command.
2. Connect to the Arctic 3G using your web browser. The default IP address of Arctic 3G is 10.10.10.10 (netmask 255.0.0.0). Note that you have to connect to a HTTPS port (see figure 3.1).




Figure 3.1: Browser https example

3. Your browser may mention about certificates, you can safely ignore them at this point.
4. When you get to the login screen, enter username and password and press Login button. The actual screen depends on the used web browser.

Note: Default username is viola-adm and default password is violam2m. It is recommended that the default password is changed before the product is connected to a public network.

- Now you should be logged in. White texts on the blue background on the left are the primary navigation texts and they are always visible on the screen. Individual screens may have their own tabs which split the configuration fields on larger screens. See figure 3.2.




Figure 3.2: Configuration menu

### 3.4 Configuring Ethernet LAN

- Select **Network->Ethernet LAN** from the left menu.
- Enter your preferred configuration to the configuration fields.
- Press **Submit** button on the bottom to save the settings.
- Select **Tools->Reboot** from the left menu and press **Reboot** button to restart the unit

Note: If you change the IP addresses, your existing web browser connection hangs up after you apply the settings, so open a new connection to the new IP address (check your Ethernet cabling)

- Now you should be able to connect to the Arctic 3G with your new IP address.

### 3.5 Configuring Mobile WAN (3G)

- Select **Network->Mobile WAN (3G)** from the left menu.
- Enter your preferred configuration to the configuration fields.
- Press **Submit** button on the bottom to save the settings.



### 3.6 Configuring default gateway

1. Select **Network->WAN Failover** from the left menu.
2. Set **"WAN Default Route"="Yes"**. This has to be enabled to use either WAN as default route interface.
3. If you want to use 3G as default gateway, set **"Primary WAN Interface"="Mobile WAN (3G)"**.
4. If you want to use Ethernet WAN as default gateway, set **"Primary WAN Interface"="Ethernet WAN"**.
5. If you have both Ethernet WAN and Mobile WAN configured, you can define the Backup WAN Interface. If the primary WAN interface comes down, Arctic 3G automatically switches default route to backup WAN interface. Figure 3.3 shows example configuration where Ethernet WAN is configured as default route.

You can define the priority of the WAN interfaces.

General Settings		
WAN Default Route	<input type="button" value="Yes"/>	Usually "Yes". If default route is defined by "static routes" or if the selection logic is done on VPN level select "No"
On Demand	<input type="button" value="No"/>	Select "Yes" to activate the backup interfaces only when required. Select "No" to have all the WAN interfaces to be available simultaneously for e.g. VPNs.
Recovery Interval	<input type="text" value=""/> [minutes]	How often the availability of higher priority WAN is checked when using lower priority WAN. Leave empty to try only when lower priority terminates.
Recovery Hysteresis	<input type="text" value=""/> [seconds]	How many seconds the higher priority WAN must be available before starting to use it again
Primary WAN		
Interface	<input type="button" value="Ethernet WAN"/>	Select the primary WAN interface
Failure Tolerance	<input type="button" value="1"/> [times]	Number of WAN connection retries before switching to lower priority connection.
Backup WAN		
Interface	<input type="button" value="None (disabled)"/>	Select the backup WAN interface
Failure Tolerance	<input type="button" value="1"/> [times]	Number of WAN connection retries before switching to lower priority connection.
Secondary Backup WAN		
Interface	<input type="button" value="None (disabled)"/>	Select the secondary backup WAN interface
Failure Tolerance	<input type="button" value="1"/> [times]	Number of WAN connection retries before switching back to primary connection.

Figure 3.3: Ethernet WAN default route example

6. Press **Submit** button on the bottom to save the settings.
7. Select **Tools->Reboot** from the left menu and press **Reboot** button to restart the unit.

# Chapter 4

## Network Configuration

### 4.1 Configuration screens

#### 4.1.1 Host and domain names

Host and domain names can be set from the System General Settings screen.

General Settings		
Hostname	<input type="text" value="localhost"/>	Name of the device, without domain part e.g. <i>station_xyz</i>
Domain	<input type="text" value="localdomain"/>	Domain name e.g. <i>mydomain</i>
Location	<input type="text"/>	You may enter installation location here for your reference (free text).
Contact	<input type="text"/>	You may enter administrator contact here for your reference (free text).
Description	<input type="text"/>	You may enter notes here for your reference (free text).

Figure 4.1: General settings

#### 4.1.2 Ethernet WAN

This screen configures the Ethernet WAN interface on Arctic 3G.

These settings define the wired internet connection (Ethernet interface "WAN"). These settings are *not* required if the Mobile WAN (3G) only is used to access the internet.

Manual Settings		
Enable	<input type="button" value="Yes"/>	Use wired WAN to access the internet?
IP Address	<input type="text" value="172.16.18.101"/>	IP Address of WAN Ethernet interface
Netmask	<input type="text" value="255.255.0.0"/>	Network Mask of WAN Ethernet interface
Gateway	<input type="text" value="172.16.1.1"/>	IP address of router used to reach the internet. Leave empty if unused.
Backup Gateway	<input type="text"/>	IP address of backup router used to reach the internet. Leave empty if unused.
DNS Servers	<input type="text"/>	Specify the DNS server addresses if required.
MTU	<input type="text"/> [bytes]	Network Maximum Transmission Unit. Normally empty.

Connectivity Monitor settings are required when "WAN Failover" is used. Otherwise use Network->Monitor.

Connectivity Monitor		
Ping Target	<input type="button" value="None (Ping Disabled)"/>	Enable to monitor the WAN connection
Ping IP	<input type="text"/>	Specify IP addresses to Ping when required
Interval	<input type="text"/> [sec]	How often to perform Ping test (empty:60 seconds)
Timeout and Retries	<input type="text"/> [sec] <input type="button" value="1"/> [times]	How long to wait response for each Ping and how many times to retry.

Figure 4.2: Ethernet WAN configuration

With the current firmware only manual configuration is supported. Automatic configuration using DHCP is not supported.

Connectivity Monitor settings are used when WAN redundancy functionality is wanted. Monitor keeps checking the connection to given remote host to determine the network status. If the ping does not get an answer for given time window, it informs the WAN switch logic to try the secondary interface.

If the WAN redundancy is implemented by using two separated Ethernet connections with different gateways, the Backup Gateway parameter needs to be configured towards correct backup gateway. Backup Gateway parameter is not needed if WAN redundancy is implemented with wireless connection.

See section 4.1.4 for more details about WAN redundancy.

### 4.1.3 Mobile WAN (3G)

This screen configures the Mobile WAN (3G) interface on Arctic 3G.

These settings define the Mobile WAN connection used to access the internet. These settings are *not* required if the Ethernet WAN only is used to access the internet.

Basic Settings		
Enable	<input type="button" value="Yes"/>	Enable in order to use Mobile WAN (3G/EDGE/GPRS).
PIN Code	<input type="text" value="0000"/>	If the SIM card requires PIN code enter it here.
Network Login		
APN	<input type="text" value="internet"/>	Mobile network Access Point Name as specified by the network operator.
Authentication	<input type="button" value="None"/>	Authentication method as specified by the network operator
Username	<input type="text" value="user"/>	Mobile network user name as specified by the network operator.
Password	<input type="text" value="pass"/>	Mobile network password as specified by the network operator.
DNS Selection	<input type="button" value="None"/>	DNS Server selection. <b>* May not be available on all networks.</b>
DNS Servers	<input type="text"/>	Specify the DNS server addresses if Selection type is "manual"

Connectivity Monitor settings are required when "WAN Failover" is used. Otherwise use Network->Monitor.

Connectivity Monitor		
Ping Target	<input type="button" value="None (Ping Disabled)"/>	Enable to test the Mobile WAN connection. <b>* May not be available on all networks.</b>
Ping IP	<input type="text"/>	Specify IP addresses to Ping when required
Interval	<input type="text"/> [sec]	How often to perform Ping test (empty:600 seconds)
Timeout and Retries	<input type="text"/> [sec] <input type="button" value="1"/> [times]	How long to wait response for each Ping and how many times to retry.

Normally Advanced Settings can be left to default values.

Advanced		
Network Service	<input type="button" value="Automatic"/>	Automatic selects the fastest available
Frequency Band	<input type="button" value="Automatic"/>	Normally Automatic is suitable
Operator	<input type="text"/>	To allow only certain operator define the PLMN code here. Normally empty.
MTU	<input type="text"/> [bytes]	Network Maximum Transmission Unit. Normally empty.
Idle Timeout	<input type="text"/> [sec]	The Mobile WAN connection is restarted when it has been unused for given timeout.
Duration	<input type="text"/> [min]	The Mobile WAN connection is restarted when it has been connected for given time.
Reconnect Interval	<input type="button" value="Constant"/> <input type="text"/> [sec]	How many seconds to wait between failed connection attempts.

Figure 4.3: Mobile WAN configuration

To configure the mobile WAN (3G), enable the connection by selecting **"Enable"="Yes"** on the top of the page and enter PIN code if set, APN name and authentication details if needed.

If Arctic 3G acts as a wireless router to Ethernet devices and DNS is needed, enter DNS configuration as well. When ready, press the **Submit** button on the bottom of the page to save settings.

Arctic 3G needs to be restarted before 3G configuration gets active.

### 4.1.4 WAN Failover

WAN Failover screen configures the default gateway settings on the Arctic 3G.

You can define the priority of the WAN interfaces.

General Settings		
WAN Default Route	<input type="button" value="Yes"/>	Usually "Yes". If default route is defined by "static routes" or if the selection logic is done on VPN level select "No"
On Demand	<input type="button" value="No"/>	Select "Yes" to activate the backup interfaces only when required. Select "No" to have all the WAN interfaces to be available simultaneously for e.g. VPNs.
Recovery Interval	<input type="text" value=""/> [minutes]	How often the availability of higher priority WAN is checked when using lower priority WAN. Leave empty to try only when lower priority terminates.
Recovery Hysteresis	<input type="text" value=""/> [seconds]	How many seconds the higher priority WAN must be available before starting to use it again
Primary WAN		
Interface	<input type="button" value="Ethernet WAN"/>	Select the primary WAN interface
Failure Tolerance	<input type="button" value="1"/> [times]	Number of WAN connection retries before switching to lower priority connection.
Backup WAN		
Interface	<input type="button" value="None (disabled)"/>	Select the backup WAN interface
Failure Tolerance	<input type="button" value="1"/> [times]	Number of WAN connection retries before switching to lower priority connection.
Secondary Backup WAN		
Interface	<input type="button" value="None (disabled)"/>	Select the secondary backup WAN interface
Failure Tolerance	<input type="button" value="1"/> [times]	Number of WAN connection retries before switching back to primary connection.

Figure 4.4: WAN Failover configuration

To enable any default routes, set **"WAN Default Route"="Yes"**. Any route settings are not effective if this parameter is not enabled.

Set **"On Demand"="Yes"** if you want the backup WAN interface to come up only when primary interface goes down. Disable if both wireless and wired WAN interfaces have to be up all the time.

#### 4.1.5 Ethernet LAN

This screen configures the Ethernet LAN interface on Arctic 3G.

These settings define Local Area Network properties (Ethernet interfaces "LAN").

Manual Settings		
Enable	<input type="button" value="No"/>	Use Ethernet LAN?
IP Address	<input type="text" value="172.16.18.100"/>	IP Address of LAN Ethernet interface
Netmask	<input type="text" value="255.255.0.0"/>	Network Mask of LAN Ethernet interface

Figure 4.5: Ethernet LAN configuration

Ethernet LAN configuration is very simple. It configures the IP address for the Ethernet LAN interface.

#### 4.1.6 Network monitor

This screen configures the interface connectivity monitor on Arctic 3G.

The monitor sends ping packets to defined targets and waits for reply. If reply is not received 3G and VPN connections are re-started.

Pinger Settings		
Enable	<input type="button" value="No"/>	Enable testing network connections. When using 3G/VPN the use of monitor is heavily recommended in order to detect connection drops.
Target	<input type="text" value=""/>	IP address of primary target to ping. The IP address must be reachable over 3G or VPN.
Secondary target	<input type="text" value=""/>	Secondary IP address to ping if the primary fails
Interval	<input type="text" value="200"/> [secs]	How often to perform the ping (default 200 secs)
Timeout	<input type="text" value="20"/> [secs]	How long to wait for ping response (default 20 secs)
Retries	<input type="text" value="3"/> [times]	How many ping retries per each test.
Failure Limits		
WAN Restart	<input type="text" value="2"/> [times]	How many failed tests before re-starting WAN and VPN (default 2)
Reboot	<input type="text" value="4"/> [times]	How many failed tests before rebooting the system (default 4)

Figure 4.6: Network monitor configuration

When using 3G/VPN the use of monitor is heavily recommended to detect connection drops.

## 4.2 Routing

### 4.2.1 Routing parameters

There are multiple configuration options that define the routing on Arctic 3G:

- Ethernet WAN - Gateway (IP address)
  - IP address of router used to reach the internet. Leave empty if unused.
- Ethernet WAN - Backup Gateway (IP address)
  - IP address of backup router used to reach the internet. Leave empty if unused.
- WAN Failover - WAN Default Route (selection: Yes/No)
  - Usually "Yes" if default route is defined by "static routes". If the selection logic is done on VPN level select "No"
- WAN Failover - On Demand (selection: Yes/No)
  - Select "Yes" to activate the backup interfaces only when required. Select "No" to have all the WAN interfaces to be available simultaneously for e.g. VPNs.
- WAN Failover - Primary WAN Interface (selection: None/Mobile WAN/Ethernet WAN/Ethernet WAN Secondary)
- WAN Failover - Backup WAN Interface(selection: None/Mobile WAN/Ethernet WAN/Ethernet WAN Secondary)
- WAN Failover - Secondary Backup WAN Interface (selection: None/Mobile WAN/Ethernet WAN/Ethernet WAN Secondary)
  - These three settings configure the high level default gateways. Must be configured to enable default route.
- OpenVPN Client Settings - Interface (selection: Any WAN/Ethernet WAN/Wireless WAN/Ethernet LAN)
  - Which Interface to use for connection
- OpenVPN Client Settings - Routing mode (selection: None/host/net/default route)
  - This defines how the routing is configured with OpenVPN. See OpenVPN application note.

### 4.2.2 Default route

Default route can be configured from WAN Failover screen. See section 4.1.4.

### 4.2.3 WAN redundancy/failover

To configure redundancy between WAN interfaces, configure multiple WAN interfaces to WAN Failover. See section 4.1.4.

### 4.2.4 Routing serial <-> Ethernet

See section 5.1 for configuring serial gateway.

## 4.3 Network services

### 4.3.1 DNS proxy

DNS proxy allows the Arctic 3G to act as a DNS server to devices connected to Ethernet LAN. The configuration is located in **Services->Common** screen.

To use this feature, configure the device to use Arctic 3G Ethernet LAN IP address as its DNS server. This way the DNS queries from the device get routed thorough the Arctic 3G.

## 4.4 Network status information

### 4.4.1 System status screen

Network status information can be seen from **System->Status** screen.

System Status information.

Network Interfaces
<pre> gprs0 Link encap:Point-to-Point Protocol inet addr:88.194.209.226 P-t-P:10.84.84.84 Mask:255.255.255.255 UP POINTOPOINT RUNNING NOARP MULTICAST MTU:1500 Metric:1 RX packets:8 errors:0 dropped:0 overruns:0 frame:0 TX packets:7 errors:0 dropped:0 overruns:0 carrier:0 collisions:0 txqueuelen:3 RX bytes:54 (54.0 b) TX bytes:81 (81.0 b)  lo Link encap:Local Loopback inet addr:127.0.0.1 Mask:255.0.0.0 UP LOOPBACK RUNNING MTU:18436 Metric:1 RX packets:0 errors:0 dropped:0 overruns:0 frame:0 TX packets:0 errors:0 dropped:0 overruns:0 carrier:0 collisions:0 txqueuelen:0 RX bytes:0 (0.0 b) TX bytes:0 (0.0 b)  wan0 Link encap:Ethernet HWaddr 00:08:70:01:04:59 inet addr:172.16.18.101 Bcast:172.16.255.255 Mask:255.255.0.0 UP BROADCAST RUNNING MULTICAST MTU:1500 Metric:1 RX packets:123 errors:0 dropped:0 overruns:0 frame:0 TX packets:43 errors:0 dropped:0 overruns:0 carrier:0 collisions:0 txqueuelen:1000 RX bytes:13229 (12.9 Kb) TX bytes:12120 (11.8 Kb) Base address:0x8400           </pre>
Routing Table
<pre> Kernel IP routing table Destination Gateway Genmask Flags Metric Ref Use Iface 10.84.84.84 0.0.0.0 255.255.255.255 UH 0 0 0 gprs0 172.16.0.0 0.0.0.0 255.255.0.0 U 0 0 0 wan0 0.0.0.0 172.16.1.1 0.0.0.0 UG 0 0 0 wan0           </pre>
Firmware Version
Arctic 3G Gateway 1.2.5

Refresh

Figure 4.7: Network status screen

### 4.4.2 Mobile WAN (3G) status LEDs

Status of mobile WAN interface can be seen from the front panel LEDs. The initialization sequence is:

1. COM LED starts to blink when the connection is started
2. SIM LED starts to blink when SIM card is searched and turns on when card is found and PIN code accepted
3. SIG LED starts to blink when operator network is searched and gets lit when the network is found
4. COM LED gets lit when the connection is up

### 4.4.3 Modem info screen

In troubleshooting situations checking the system logs helps to identify the problem. Also modem info page can be used to check the status of the wireless modem.

Information about the Wireless WAN network. Updated only on connection start.

General Information	
Wireless WAN	Enabled (Up)
Last Information Update	Tue Dec 09 07:14:48 2008 (28 hours ago)
Modem Information	
Manufacturer	Sierra Wireless, Inc.
Type	AC850
IMEI	357807002253596
Supported Services	GSM,GPRS,EDGE,UMTS,HSDPA
PIN tries used	0
SIM status	PIN not required
Network Information	
Signal Level	-86 dBm (74 %,normal)
Registration Status	registered to home network
Available Services	UMTS
Current Service	UMTS
Current Operator	24491 FI SONERA
Location Area Code	138D
Cell ID	D6D1

Refresh

Figure 4.8: Modem info screen

## Chapter 5

# Serial Port Configuration

### 5.1 Configuring serial gateway

This section describes how to configure serial <-> Ethernet functionality.

Serial gateway feature enables data from the serial port attached device to be routed to Ethernet and vice versa. Serial gateway processes the transmitted data transparently and does not alter it any way except for buffering it for transmission. Because of the transparent communication, any protocols can be used in actual communication between nodes.

Serial-to-Network Gateway application for serial port RS1.

Basic Settings	
Enable	No <input type="button" value="v"/> Use Serial-to-Network Gateway
Network Protocol	TCP <input type="button" value="v"/> Which protocol to use for network communication (usually TCP)
Mode	Server <input type="button" value="v"/> Wait for incoming connection (Server) or actively form a connection (Client)
New Connection priority	Yes <input type="button" value="v"/> Close old connection when new connection request arrives (server mode only)
Connection Slot	<input type="text"/> [sec] How long the old connection must be connected before accepting new one (only in server mode with new connection priority enabled)
Local Port	7001 <input type="text"/> Which TCP/UDP port to listen (only in server mode)
Remote Server	<input type="text"/> [host] <input type="text"/> [port] Remote server IP address and remote port to connect (only in client mode)
Idle Timeout	<input type="text"/> [sec] Close connection when it has been idle over defined timeout (empty=infinite)
Serial Port	
Serial Settings	9600 <input type="button" value="v"/> 8 <input type="button" value="v"/> None <input type="button" value="v"/> 1 <input type="button" value="v"/> Serial port speed, data bits, parity and stop bits.
Serial Handshaking	None <input type="button" value="v"/> Serial port handshaking. For RS-422/485 select "None"
Flush old data	Yes <input type="button" value="v"/> Empty serial data buffers when new connection arrives
Framing	
Serial Frame Spacing	100 <input type="text"/> [ms] Detect serial frame to end when defined gap on data
Serial Frame Size	<input type="text"/> [bytes] Detect serial frame to end when defined amount of bytes received
Network Frame Spacing	<input type="text"/> [ms] Detect network frame to end when defined gap on data
Network Frame Size	<input type="text"/> [bytes] Detect network frame to end when defined amount of bytes received

Figure 5.1: Serial gateway configuration screen

Serial gateway configuration depends on used protocols.


Both serial ports have their own configuration screens, located in **Applications->Serial Gateway (RS1)** and **Applications->Serial Gateway (RS2)**.

## Chapter 6

# Additional System Configuration

### 6.1 Changing system password

Username and password can be changed from **Tools->User Config** screen. It is always recommended to change the password from the factory default when the Arctic 3G is connected to a public network.



WebUI User	
Username	viola-adm
Password	violam2m


Submit Reset

Figure 6.1: User config screen

New username and password will be active after the Arctic 3G is restarted.

### 6.2 Date and time

Date and time can be changed from **System->Time** screen. Date and time can be configured either manually entering the time or automatically from connected PC.



The Current System Date and Time. Set either manually or click 'Copy PC' which copies system time from your PC clock.

Current Time and Date	
Time	15 : 37 : 56
Date	01 October 2008
PC Time	Oct 1 15:38:10 2008

Submit Copy PC

Figure 6.2: System time configuration screen

To set time manually, enter the time and then press **Submit** button.

To copy time from PC, press **Copy PC** button and answer “Yes” to question about changing time. Note that the PC may not necessarily have correct time set and that needs validation. Also note that the copy functionality requires JavaScript support from the browser.

### 6.3 System log

System log is visible on the **Tools->System Log** screen. To refresh the system log, use web browser reload button.

### 6.4 Factory default settings

Factory default settings can be applied by restarting the unit pressing down reset button until the LEDs blink.



## 6.5 Firmware update

Current running firmware version can be seen from the **System->Status** screen.

Arctic 3G firmware can be updated from the **Tools->Firmware Update** screen.




Figure 6.3: Firmware update screen

Note that firmware update erases all the settings on the unit to the factory defaults. It is recommended to create backup from the old configuration before attempting to update the firmware.

To update firmware:

1. Verify that you have a valid firmware on your PC before you attempt to update the firmware.
2. Select **Select file** button to open file browsing dialog. The actual dialog depends on the used browser.
3. Select updated firmware from the file dialog and return to firmware update screen.
4. Press **Update** button to start the firmware update.
5. Confirm the update when asked to.

Update takes few minutes and the unit will restart with factory default settings when the update is done.

# Chapter 7

## Troubleshooting

### Q: Wireless WAN is not coming up

A: Check settings, SIM card and signal level. Easy way to check the connection status is checking the LEDs, see section 4.4.2.

### Q: OpenVPN is not working

A: See OpenVPN application note for more information.

### Q: Serial ports are not working

A: See serial port chapter notes. Verify DIP switch configuration if you are using RS-422 or 485 modes.

### Q: Can not access web user interface

A: Web user interface uses HTTPS for secure web access and it must be specified on the web browser address field like in this example: `https://10.10.10.10`.

### Q: Can not access the Internet with laptop connected to Arctic 3G

A: If you want to test the 3G connection:

1. Configure 3G connection and verify it connects to the network
2. Connect a laptop to Ethernet LAN
3. Check that S-NAT rule on the firewall is set as **"Action"="Masquerade"** and **"Destination Interface"="Mobile WAN (3G)"**.
4. Check that DNS Proxy is enabled from **Services->Common** screen.
5. Configure network settings on laptop to use Arctic 3G Ethernet LAN address as gateway and DNS server.

With these settings you should be able to access the Internet with the laptop.

## Chapter 8

# Technical Specifications

Processor	PowerPC 400MHz
Memory	64MB
Hard Drive	32MB flash
Input voltage	11-18 Volts
Power consumption	7W max
Power connector	Phoenix Contact MC 1,5/ 3-STF-3,5
Casing	Aluminium sheet
Operating temperature	0 ... +70 C
Storage temperature	-40 ... +85 C
Humidity	0 ... 99 % non-condensing
Network connection	10/100M
Approvals	CE
Size	168 x 115 x 30 mm
Weight	560 g

Table 8.1: Technical specifications

Networks	Frequencies	Maximum data rates
UMTS with HSDPA (cat 11/12)	2100 MHz	1.8Mbps downlink / 384kbps uplink
EDGE/GPRS class 10	850/900/1800/1900 MHz	216 kbps downlink/ 108 kbps uplink

Table 8.2: Wireless specifications

Antenna connector type is SSMB-nano.

Serial mode (RS1)	RS-232 / 422 / 485
Serial mode (RS2)	RS-232
Baud rate	300 - 460800
Data bit	5 / 6 / 7 / 8
Parity	None / Even / Odd
Stop bits	1 / 2
Flow control	None / Hardware (RTS/CTS) / Software (XON/XOFF)

Table 8.3: Application serial port specifications

Technical specifications can be changed without notification.

## Chapter 9

# Limited Warranty

### Coverage

Viola Systems warrants this hardware product to be free from defects in materials and workmanship for the warranty period. This non-transferable, limited warranty is only to you, the first end-user purchaser. The warranty begins on the date of purchase and lasts for the period specified below:

Arctic 3G Gateway	one (1) year
-------------------	--------------

### Excluded Products and Problems

This warranty does not apply to: (a) Viola Systems software products; (b) expendable components such as cables and connectors; or (c) third party products, hardware or software, supplied with the warranted product. Viola Systems makes no warranty of any kind on such products which, if included, are provided "AS IS." Excluded is damage caused by accident, misuse, abuse, unusually heavy use, or external environmental causes.

### Remedies

Your sole and exclusive remedy for a covered defect is repair or replacement of the defective product, at Viola Systems' sole option and expense, and Viola Systems may use new or refurbished parts or products to do so. If Viola Systems is unable to repair or replace a defective product, your alternate exclusive remedy shall be a refund of the original purchase price.

The above is Viola Systems' entire obligation to you under this warranty. IN NO EVENT SHALL VIOLA SYSTEMS BE LIABLE FOR INDIRECT, INCIDENTAL, CONSEQUENTIAL OR SPECIAL DAMAGES OR LOSSES, INCLUDING LOSS OF DATA, USE, OR PROFITS EVEN IF VIOLA SYSTEMS HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. In no event shall Viola Systems' liability exceed the original purchase price of the device server. Some states or countries do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.

### Obtaining Warranty Service

You must notify Viola Systems within the warranty period to receive warranty service. During the warranty period, Viola Systems will repair or replace, at its option, any defective products or parts at no additional charge, provided that the product is returned, shipping prepaid, to Viola Systems. All replaced parts and products become the property of Viola Systems. Before returning any product for repair, customers are required to contact the Viola Systems.

## Chapter 10

# Technical Support

### Contacting Technical Support

- Phone: +358 20 1226 226
- Fax: +358 20 1226 220
- E-mail: [support@violasystems.com](mailto:support@violasystems.com)
- On-line <http://www.violasystems.com>

### Recording Product Information

Before contacting our Technical Support staff, record the following information about your product:

- Product name.:
- Serial no.:

Note the status of your product in the space below before contacting technical support. Include information about error messages, diagnostic test results, and problems with specific applications.

# Index

3G settings, 18

Accessories, 13

Antenna specification, 9

Back panel, 7

Console adapter, 11

Contact information, 3

Copyright and trademark, 3

Date, 23

Default gateway, 16

DIN rail mounting, 12

DIP switches, 11

Disclaimer, 4

DNS proxy, 20

Domain name, 17

Ethernet specifications, 10

Ethernet WAN specifications, 10

Factory default settings, 23

Features, 6

Firmware update, 24

Front panel, 7

Hostname, 17

LEDs, 8

Limited warranty, 27

Logging in, 14

Modem info, 21

Network monitor, 19

Packaging, 6

Password, 23

Power connector, 12

Power switch, 12

Product label, 13

Quick installation, 14

Reset button, 12

Revision history, 4

Routing table, 21

RS-422/485, 11

Serial console, 10

Serial gateway, 22

Serial port 1, 11

Serial port 2, 12

Side panel, 8

SIM card installation, 9

Specifications, 26

System log, 23

System status screen, 21

Technical support, 28

Time, 23

Troubleshooting, 25

Username, 23

Warranty, 5

Wireless WAN specifications, 9